


# Self-Hosted Management Software for Enterprise Environment Monitoring Systems

## ENVIROMUX®

- Units may be monitored individually or in a group.
- Display values and status for individual sensors or list of sensors.
- Self-hosted software – ideal for users in industries that require local software management solutions for security or data privacy purposes.
  - Install on a Windows-based server or computer.
    - Operating system requirements: Windows 7/8/10/11 32-bit or 64-bit, Windows Server 2008/2012/2016/2019/2022 32-bit or 64-bit.
    - Virtual machines are NOT supported at this time.
- Any computer, smartphone, and/or tablet with a web browser installed can be used to access the software.
  - Access is operating system independent through the HTML5 user interface on the computer/smartphone/tablet's web browser.
  - No clients or special apps to install.
- Supports 1,000 users accessing the software program at the same time.
  - Users can configure their own dashboards to display the data relevant to them and the window arrangement.
    - Customize dashboards to display unit status, sensor data, gauges, graphs, and IP camera snapshots.
- Configure pre-loaded geographical maps or upload custom floor plan maps/images for a visual representation of sensor locations.
  - Provides users with a real-time view of their facility, and the physical location and status of all connected ENVIROMUX environment monitoring systems and sensors.
- Schedule and customize PDF reports that can be viewed/saved in the software and emailed to selected users.
- Saves up to 1,000 user-programmable IP camera recordings.
  - Any programmed event can trigger a recording from an IP camera.
  - Recordings are created using snapshots captured based on the refresh rate set for the IP camera.
    - Recording duration can be set between 5 seconds and 10 minutes.
    - Each recording is labeled with the name of the camera the images are captured from with the date/time.
- One-time purchase – no monthly fees.
- NTI will provide customer, without charge, copies of any appropriate updates/enhancements for 12 months. This software update service is optionally extendable every twelve months for 20% of list price.
  - Features coming soon in upcoming releases:**
    - Full HTTPS support with auto host-name update and certificate generation.
    - Support for IP sensors on E-xD.
    - Support for E-MICRO and E-1W monitoring systems.
    - Support for live stream video from IP cameras.
    - Support for running the software as a Windows service.
    - Auto discovery of NTI devices from server.
    - Download data logs.
    - Support for auto load of E-xD configuration when changes are made directly on E-xD unit.
    - Email alerts from the software.
    - Push notifications from browser on Android and iPhone smartphones/tablets.
    - Plot the placement of E-LLDC-xx Liquid Location Detection Sensor Cables on floor plan maps to visually see the specific location of liquid presence when detected.



### E-MNG-SH

#### Self-Hosted Enterprise Environment Monitoring System Management Software

- Self-hosted software.**
- No clients or special apps to install.**
- Access from anywhere using a web browser on a computer, smartphone, &/or tablet.**
- Monitor & configure up to 3,000 units & all connected sensors.**
- Display values and status for individual or list of sensors.**
- Customizable monitoring and layout for each user.**
- One-time purchase – no monthly fees.**

Optional Management Software for E-2D/5D/16D.

E-MNG-SH is a self-hosted software program that provides an easy-to-use, unified interface for monitoring and configuring up to 3,000 E-2D/5D/16D units and all connected sensors (internal, external, and digital input) and output relays via Ethernet. The software is installed on a Windows-based server or computer to actively poll all units for status information and alerts. Any computer, smartphone, or tablet with a web browser can be used to access the software. It allows users to be kept up to date on sensor statuses and be alerted instantly when a sensor goes out of range of a configurable threshold.